

Pocket Testers



Standard battery: 4X 1.5V AAA

Data locking function

1-3 Calibration points

Locking ring
Designed with replaceable probes,
Combines pH/Cond/TDS/RES/Sal.
altogether

Backlight display color:
White color: measurement mode
Green color: calibration mode
Red color: alarm mode activated

Sample ID classification and
measurement information share

Power key

- When turned off, short press to turn on the tester; long press to enter parameter setting.
- When turned on, long press to turn off the tester, short press to turn on/off backlight or exit set-up mode.

MODE key

- Long press to turn on/off Bluetooth connection
- short press to switch parameter

CAL/ENT key

- Long press to enter calibration mode.
- Short press to manually lock/unlock reading.



DPC1/DPC1+